

DIGIT DISPLAY

WALLET CALCULATOR

**UNV-15907** Owner's Manual



## **OPERATING THE CALCULATOR**

ON/C•CE Key — Power ON / Clear LCD / Clear Entry. Power OFF after a few minutes if no button is pressed. If a result is too big to show in the LCD, the calculator stops and displays E. Press ON/C•CE to continue.

Metal Carrying Case – Protects the calculator wherever you go.

+/- Key - Press to change the displayed number from positive (+) to negative (-) or from negative (-) to positive (+).MINUS - is displayed when the value is negative.

#### **MEMORY FUNCTIONS**

[M+] Press to add the displayed number to memory

**MEMORY** is displayed.

[M-] Press to subtract the currently displayed number from memory.

[MR] Recall the number in memory.

[MC] Clear the memory.

# Percentages (%)

Calculate 6% of 200.

Press [2] [0] [0] [x] [6] [%]

12

Add 6% tax to a \$20 purchase.

Press [2] [0] [+] [6] [%] 21.2

Calculate 20% discount from \$150.

Press [1] [5] [0] [x] [2] [0] [%]

30

#### REPLACING THE BATTERY

- 1. Remove the two screws on the rear panel. Using a flat edge, pry open the rear panel.
- 2. Slide out the old battery. Insert the new battery with the + side up.
- 3. Replace the rear panel.

#### **FEATURES**

**Large, 8-Digit Display** – big, easy-to-read LCD numbers.

**Four Function Memory** – includes addition, subtraction, recall, and clear.

**Dual Solar/Battery Power** – built-in solar panel extends battery life by powering the calculator in the light.

Automatic Power Off – saves battery power by turning off the calculator if it is left unused for about 7 min.

## PERFORMING CALCULATIONS

**Addition (+)** *Example:* 6 + 7 = 13 Press [6] [+] [7] [=] *13* 

**Subtraction (-)** Example: 10 - 4 = 6 Press [1] [0] [-] [4] [=] 6

**Multiplication (x)** Example: 7 x 5 = 35 Press [7] [x] [5] [=] 35

**Division (÷)** Example: 14 ÷ 7 = 2 Press [1] [4] [÷] [7] [=] 2

Square Root ( ÷ )

Calculate the square root of 64

Press [6] [4] [÷] 8

# **CARE AND MAINTENANCE**

- Keep the calculator dry. If it gets wet, dry it before use.
- Do not use harsh solvents or detergents to clean the unit.
- Do not drop or strike the calculator.